

نحوه ی آپگرید کردن

تلفن Grandstream

کاوا ارتباطات هوشمند

ارتباطات یکپارچه صوت، تصویر و دیتا

www.Kavatelecom.com

www.VoIPshop.ir

نگارش: کامبیز رضانی

تاریخ: 92/09/11

1- بعد از وارد شدن به وب، به قسمت advanced settings می رویم.

Grandstream Device Configuration

STATUS	BASIC SETTINGS	ADVANCED SETTINGS	ACCOUNT 1	ACCOUNT 2	ACCOUNT 3	ACCOUNT 4	EXT 1	EXT 2
<p>MAC Address: 00:0B:82:27:DB:D6</p> <p>IP Address: 192.168.15.89</p> <p>Product Model: GXP2000 (HW2.2A)</p> <p>Part Number: 9620000522A</p> <p>Software Version: Program-- 1.2.5.3 Bootloader-- 1.1.6.9</p> <p>System Up Time: 0 day(s) 0 hour(s) 4 minute(s)</p> <p>System Time: 12:04am Tuesday, January 2, 1900</p> <p>Registered: Account 1 Not Registered Account 2 Not Registered Account 3 Not Registered Account 4 Not Registered</p> <p>PPPoE Link Up: disabled</p>								

All Rights Reserved Grandstream Networks Inc. 2004-2009

- 1- قسمت firmware upgrade را روی tftp ست می کنیم.
- 2- Firmware server path آدرس سرور tftp را می دهیم.
- 3- Config server path آدرس فایل مورد نظر در سرور را وارد می کنیم.

Grandstream Device Configuration

STATUS BASIC SETTINGS ADVANCED SETTINGS ACCOUNT 1 ACCOUNT 2 ACCOUNT 3 ACCOUNT 4 EXT 1 EXT 2

Admin Password: (purposely not displayed for security protection)

G723 rate: 6.3kbps encoding rate 5.3kbps encoding rate

iLBC frame size: 20ms 30ms

iLBC payload type: (between 96 and 127, default is 97)

Silence Suppression: No Yes

Voice Frames per TX: (up to 10/20/32/64 for G711/G726/G723/other codecs respectively)

Layer 3 QoS: (Diff-Serv or Precedence value)

Layer 2 QoS: 802.1Q/VLAN Tag 802.1p priority value (0-7)

Data VLAN Tag: 1: 2: 3: (can't use the same non-zero value as 802.1Q tag)

No Key Entry Timeout: (in seconds, default is 4 seconds)

Use # as Dial Key: No Yes

local RTP port: (1024-65400, default 5004, must be even)

Use random port: No Yes

keep-alive interval: (in seconds, default 20 seconds)

Use NAT IP: (if specified, this will be used in SIP/SDP message)

STUN server: (URL or IP:port)

Firmware Upgrade and Provisioning: Upgrade Via TFTP HTTP

Firmware Server Path:

Config Server Path:

Firmware File Prefix:

Firmware File Postfix:

Config File Prefix:

Config File Postfix:

4- روی Update کلیک می کنیم.

System Ring Tone:

Call Progress Tones:

Dial Tone

Message Waiting

Ring Back Tone

Call-Waiting Tone

Busy Tone

Reorder Tone

Syntax: f1=val, f2=val [, c=on1/off1 [-on2/off2 [-on3/off3]]];
(Frequencies are in Hz and cadence on and off are in 10ms)

Disable Call-Waiting: No Yes

Disable Call-Waiting Tone: No Yes

Disable Direct IP Calls: No Yes

Use Quick IP-call mode: No Yes

Disable Conference: No Yes

Lock Keypad Update: No Yes (configuration update via keypad is disabled if set to Yes)

Enable MPK sending DTMF: No Yes

Disable DND Button: No Yes (MUTE/DEL button pressing will have no effect if set to Yes)

Disable Transfer: No Yes

Disable Multicast Filter: No Yes

Enable Constraint Mode: No Yes

Semi-attended Transfer Mode: RFC5589 Send REFER with early dialog

Headset TX gain (dB):

Headset RX gain (dB):

Display Language: English Chinese
 Secondary Language (Language File postfix)

Copyright Reserved Grandstream Networks Inc. 2004-2009

6-بر روی reboot کلیک می کنیم.

Grandstream Device Configuration

STATUS BASIC SETTINGS ADVANCED SETTINGS ACCOUNT 1 ACCOUNT 2 ACCOUNT 3 ACCOUNT 4 EXT 1 EXT 2

Your configuration changes have been saved.
They will take effect on next reboot.

Reboot

All Rights Reserved Grandstream Networks Inc. 2004-2009